



USER MANUAL LQT60 & LQT400




HUGO TILLQUIST AB
Box 1120
SE-164 22 KISTA
Sweden
Tel: +46 8 594 632 00
Fax: +46 8 751 36 95
E-mail: info@tillquist.com
Website: www.tillquist.com

Thank you for choosing LQT from Hugo Tillquist AB!

The LQT is a configurable multitransducer for all electrical quantities. All areas for AC current and voltage (True RMS) is covered by one single unit.

The software “ConfigLQT” enables easy configuration via the USB-port.



Contents

1	LQT product description	1
2	Installation	2
2.1	Installation measuring transducer	2
2.2	Installation software ConfigLQT	2
3	Configuration LQT.....	3
3.1	Connection LQT to computer	3
3.2	Indata – View data	3
3.2.1	Parameters monitorized	4
3.3	Configuration inputs – Transducer input settings	4
3.3.1	Connection diagrams – System connection	5
3.4	Analog Outputs	7
3.4.1	Measured quantities	8
3.5	Binary Outputs (LQT60 WIDE)	9
3.6	Save / Open saved configuration.....	9
3.6.1	Save to file	9
3.6.2	Load from file	9
4	Upgrade of firmware in LQT	10
5	Which COM-port is LQT using	14
6	Appendix	16
6.1	Technical data LQT400.....	16
6.2	Technical data LQT60.....	17

1 LQT product description

LQT is a configurable multitransducer for electrical quantities in a line. It is possible to optionally choose electrical quantity to the analog outputs. 2 transistors outputs (LQT60) can be used to energy pulses or alarm levels. The configuration is done with the software ConfigLQT via the USB-port on the LQT.

2 Installation

2.1 Installation measuring transducer

The transducer is mounted in DIN-rail 35 mm for wall mounting or rack mounting in appropriate housing. The installation is to be made by competent electrician and in accordance with existing regulations. Before installation please check that the transducer has the correct type and that the data comply with the order. The transducer is connected with clamps max 2 x 2,5 mm² in accordance with connection diagram.

Connection diagram, see page 5.

2.2 Installation software ConfigLQT

The installation package consists of configuration software and USB driver. ".NET Framework" version 4.0 must be installed on the computer otherwise ConfigLQT does not work. It is a software from Microsoft which often already is installed. If not it has to be installed. Go to : <http://www.microsoft.com/net/>. and you will find .NET Framework.

Download ConfigLQT from www.tillquist.com/eng/ and unzip the files.

1. Install driver for USB. "VCP_V1.3.1_Setup.exe" is for 32-bit Windows operative and "VCP_V1.3.1_Setup_x64.exe" is for 64-bit.
2. Install ConfigLQT.

3 Configuration LQT

3.1 Connection LQT to computer

Connect a USB-cable between the USB-port on LQT and the computer. Use cable with contacts type A and mini B.

Click *File* and choose *Connect*.

Choose COM-port and click *Open Port* and close the window *Close*.

On the tab **View data** in the field **USB Connection status** the word **Connected** is shown with a green background.

3.2 Indata – View data

In View data the various basic parameters of the transducer are configured and the present measuring values can be seen when the transducers is connected to an object. The measuring values are shown as Primary, Secondary or Raw values.

The screenshot displays the Config_LQT software interface. The main window is titled 'Config_LQT' and has a menu bar with 'File' and 'Edit'. Below the menu bar are three tabs: 'View data', 'Analog Outputs', and 'Binary Outputs'. The 'View data' tab is active, showing a 3-phase system data table with columns for L1, L2, and L3. The table includes parameters such as P, Q, S, U, U12, U23, U31, I, IS, PF, QF, LF, PA, and F. The 'F' parameter is highlighted in green, indicating a frequency of 49,978 Hz. To the right of the table are two panels: 'Transducer input settings' and 'Transducer information'. The 'Transducer input settings' panel includes fields for Primary and Secondary voltage (U) and current (I), a 'Data mode' dropdown set to 'Primary', and a 'System connection' dropdown set to '-11'. The 'Transducer information' panel lists various parameters such as Device model (LQT60-1136-A20), Input system (-11), Analog outputs (+/- 20 mA), Nominal voltage (400 V), Nominal current (5 A), Nominal frequency (50/60 Hz), Accuracy class (0.2), Auxiliary supply (24-250 VDC), Serial number (20124003), Software (SWLQTV0.83), and Firmware (FWF205UV1.03). Below these panels is a 'USB connection status' section showing a green bar and the text 'Connected'. At the bottom of the window, there is a 'Modbus Loaded' indicator and the TIIQUIST logo.

	L1	L2	L3
P	0,0 kW	0,0 kW	0,0 kW
Q	0,0 kvar	0,0 kvar	0,0 kvar
S	59,4 kVA	9,9 kVA	29,7 kVA
U	331,68 kV	331,70 kV	331,67 kV
U12, U23, U31	0,00 kV	0,00 kV	0,00 kV
I	0,000 A	0,000 A	0,000 A
IS	0,000 A	0,000 A	0,000 A
PF	0,000	0,000	-1,000
QF	0,000	-1,000	0,000
LF	0,000	-1,000	0,000
PA	123,612°	131,693°	170,101°
F	49,978 Hz		

The measuring inputs on LQT can be connected to nets with a nominal main voltage between 100 and 400 V AC and a current with a nominal value 1, 2 or 5 A. With the software ConfigLQT the unit can be used for all different connections in 1-phase and 3-phase nets.

3.2.1 Parameters monitorized

P Power $P=S*\cos(\varphi) [W]$	IS System current with sign??
Q Reactive power $Q=S*\sin(\varphi) [var]$	PF Power factor $PF=P/S$
S Appearant power $S=rot(3)*Uh*Ih [VA]$	QF Reactive power factor $QF=Q/S$
U Voltage	LF = sign(Q)*(1- PF)
I Current	PA Phase angle
	F Frequency

3.3 Configuration inputs – Transducer input settings

The screenshot shows the 'Transducer input settings' window with the following fields and callouts:

- Primary suffix:** U: V, kV, MV; I: A, kA
- Transformer ratios:** Points to the Primary and Secondary voltage and current input fields.
- Data mode:** Select value to be shown.
 - Primary – values based on primary data.
 - Secondary – values based on secondary data.
 - Raw – 100 000 = 100% compared with transducer Nominal U/I.
- System connection:** For information please see page 5.
- Transducer name:** Text field – 20 characters
- Apply settings:** Save data to transducer.
- Read settings:** Read present settings from LQT to ConfigLQT

3.3.1 Connection diagrams – System connection


Select appropriate diagram for the transducer.

-00	1-phase 1 system 4 wire 3-phase symmetric load		Aux. supply 17 ≈ 18	RS-485 A SG B	- A1 + 21 ↔ 22	- A2 + 23 ↔ 24	- A3 + 25 ↔ 26	- A4 + 27 ↔ 28	- A5 + 29 ↔ 30
-01	1-phase 1 system Single-phase AC		Aux. supply 17 ≈ 18	RS-485 A SG B	- A1 + 21 ↔ 22	- A2 + 23 ↔ 24	- A3 + 25 ↔ 26	- A4 + 27 ↔ 28	- A5 + 29 ↔ 30
-02	1-phase 1 system 3 wire 3-phase symmetric load phase-shift U12-I1		Aux. supply 17 ≈ 18	RS-485 A SG B	- A1 + 21 ↔ 22	- A2 + 23 ↔ 24	- A3 + 25 ↔ 26	- A4 + 27 ↔ 28	- A5 + 29 ↔ 30
-03	1-phase 1 system 3 wire 3-phase symmetric load phase-shift U23-I1		Aux. supply 17 ≈ 18	RS-485 A SG B	- A1 + 21 ↔ 22	- A2 + 23 ↔ 24	- A3 + 25 ↔ 26	- A4 + 27 ↔ 28	- A5 + 29 ↔ 30
-04	1-phase 1 system 3 wire 3-phase symmetric load phase-shift U31-I1		Aux. supply 17 ≈ 18	RS-485 A SG B	- A1 + 21 ↔ 22	- A2 + 23 ↔ 24	- A3 + 25 ↔ 26	- A4 + 27 ↔ 28	- A5 + 29 ↔ 30
-05	3-phase 1 system 3-phase symmetrical load		Aux. supply 17 ≈ 18	RS-485 A SG B	- A1 + 21 ↔ 22	- A2 + 23 ↔ 24	- A3 + 25 ↔ 26	- A4 + 27 ↔ 28	- A5 + 29 ↔ 30
-09	3-phase 2 system 3-wire 3-phase asymmetrical load		Aux. supply 17 ≈ 18	RS-485 A SG B	- A1 + 21 ↔ 22	- A2 + 23 ↔ 24	- A3 + 25 ↔ 26	- A4 + 27 ↔ 28	- A5 + 29 ↔ 30
-11	3-phase 3 system 4-wire 3-phase asymmetrical load		Aux. supply 17 ≈ 18	RS-485 A SG B	- A1 + 21 ↔ 22	- A2 + 23 ↔ 24	- A3 + 25 ↔ 26	- A4 + 27 ↔ 28	- A5 + 29 ↔ 30

System-connection	Application	I1	I2	I3	N	U1	U2	U3	U12	U23	U31	U =	I =	P =	Q =	S =
-00	4 wire 3 phase symmetric load	X	-	-	X	X	-	-	-	-	-	U1	I1	P1*3	Q1*3	S1*3
-01	1 wire 1 phase	X	-	-	X	X	-	-	-	-	-	U1	I1	P1	Q1	S1
-02	3 wire 3 phase symmetric load	X	-	-	-	-	-	-	X	-	-	-	-	P1U12	Q1U12	I1*U12* $\sqrt{3}$
-03	3 wire 3 phase symmetric load	X	-	-	-	-	-	-	-	X	-	-	-	P1U23	Q1U23	I1*U23* $\sqrt{3}$
-04	3 wire 3 phase symmetric load	X	-	-	-	-	-	-	-	-	X	-	-	P1U31	Q1U32	I1*U31* $\sqrt{3}$
-05	3 wire 3 phase symmetric load	X	-	-	X	X	X	X	X	X	X	-	I1	P1*3	Q1*3	S1*3
-09	3 wire 3 phase asymmetric load	X	-	X	-	X	X	X	X	X	X	-	(I1+I3)*3/2	(P1+P3)*3/2	(Q1+Q3)*3/2	(S1+S3)*3/2
-11	4 wire 3 phase asymmetric load	X	X	X	X	X	X	X	X	X	X	(U1+U2+U3)/3	(I1+I2+I3)/3	P1+P2+P3	Q1+Q2+Q3	S1+S2+S3
-11	4 wire 3 phase asymmetric load Open Delta	X	X	X	-	X	X	X	X	X	X	(U1+U2+U3)/3	(I1+I2+I3)/3	P1+P2+P3	Q1+Q2+Q3	S1+S2+S3

3.4 Analog Outputs

To configure the analog outputs select **Analog Outputs**.



Configuration by: Primary or Secondary.
Configuration of the output based on primary or secondary value.

Activating a channel.

Drop-down list to select quantity or fixed output signal.

Characteristics for the output shown as a graph

Example:
I1: 0 – 5 A
Ut: 4 – 20 mA

Secondary	Analog out
0	4
5	20
0	0
0	0
0	0

The analog outputs can freely be configured to the required measuring quantity within the allowed measuring ranges. Select the quantity that is to be connected to the analog output using the drop-down list.

In the field **Primary/Secondary** the start values is to be written in the first space and in the following space the end value and the breakpoints if any are to be indicated. Under **Analog out** the corresponding values of the output signal are indicated.

Apply settings transfer and save the new settings in the transducer.


To simulate the outputs to test for instance a panel instrument, please use the drop-down list (Fixed Output). Write the output that you desire and click *Apply settings*.

3.4.1 Measured quantities

Prefix	Quantity	Calculation	System / Phase
I	Input current	$(I1+I2+I3)/3$	System
I1	Phase current L1		L1
I2	Phase current L2		L2
I3	Phase current L3		L3
U	Input voltage	$(U1+U2+U3)/3$	System
U1	L1 Phase voltage		L1
U2	L2 Phase voltage		L2
U3	L3 Phase voltage		L3
P	Active power	$P1+P2+P3$	System
P1	Active power L1		L1
P2	Active power L2		L2
P3	Active power L3		L3
Q	Reactive power	$Q1+Q2+Q3$	System
Q1	Reactive power L1		L1
Q2	Reactive power L2		L2
Q3	Reactive power L3		L3
S	Apparent power	$S1+S2+S3$	System
S1	Apparent power L1		L1
S2	Apparent power L2		L2
S3	Apparent power L3		L3
U12	Main voltage L1-L2		L1 - L2
U23	Main voltage L2-L3		L2 - L3
U31	Main voltage L3-L1		L3 - L1
PF	Active power factor	P/S	System
PF1	Active power factor	$\cos(\varphi1)=P1/S1$	L1
PF2	Active power factor	$\cos(\varphi2)=P2/S2$	L2
PF3	Active power factor	$\cos(\varphi3)=P3/S3$	L3
QF	Reactive power factor	Q/S	System
QF1	Reactive power factor	$\sin(\varphi1)=Q1/S1$	L1
QF2	Reactive power factor	$\sin(\varphi2)=Q2/S2$	L2
QF3	Reactive power factor	$\sin(\varphi3)=Q3/S3$	L3
LF	LF factor	$\text{sign}(Q)*(1- PF)$	System
LF1	LF factor	$\text{sign}(Q1)*(1- PF1)$	L1
LF2	LF factor	$\text{sign}(Q2)*(1- PF2)$	L2
LF3	LF factor	$\text{sign}(Q3)*(1- PF3)$	L3
PA	Phase angel	$PA=(PA1+PA2+PA3)/3$	System
PA1	Phase angel	$\varphi1=\text{ARCCOS}(P1/S1)/\text{PI}*180*\text{sign}(P1)$	L1
PA2	Phase angel	$\varphi2=\text{ARCCOS}(P2/S2)/\text{PI}*180*\text{sign}(P2)$	L2
PA3	Phase angel	$\varphi3=\text{ARCCOS}(P3/S3)/\text{PI}*180*\text{sign}(P3)$	L3
IS	Input current with sign	$(IS1+IS2+IS3)/3$	System
IS1	Phase current with sign	$I1*\text{sign}(P1)$	L1
IS2	Phase current with sign	$I2*\text{sign}(P2)$	L2
IS3	Phase current with sign	$I3*\text{sign}(P3)$	L3
P_I1_U12	Active power, System connection-02		System
P_I1_U23	Active power, System connection -03		System
P_I1_U31	Active power, System connection -04		System
Q_I1_U12	Reactive power, System connection -02		System
Q_I1_U23	Active power, System connection -03		System
Q_I1_U31	Active power, System connection -04		System
F	Frequency		System
Fixed Output	Fixed output		

3.5 Binary Outputs (LQT60 WIDE)

To configuration the binary outputs, select the **Binary outputs**.



3.6 Save / Open saved configuration

The stored parameters in the LQT can be saved to a file.

3.6.1 Save to file

1. Select *File* and *Save file*.
2. Write filename and select folder.

3.6.2 Load from file


1. Select *File* and *Open file*.
2. Select saved configuration file (XML-dokument).

4 Upgrade of firmware in LQT


LQT firmware is upgraded with ConfigLQT. Connect the computer to the USB port of the computer. Find out which COM-port that LQT is connected to.

You find information about this in "Windows Device Manager" section "Ports". See page 14, chapter 5 for further information.


1. Start Config LQT.
2. Select *File* and *Connect*.
3. Select COM-port in the drop-down list and click *Open*




4. Close the window with *Close*.
5. Select: *File* and *Firmware upgrade*.




6. Information about the available firmware versions that can be installed with this version of Config LQT is shown. In case a new version of firmware is installed the latest version of ConfigLQT must be chosen.




7. Select firmware file.




8. Click *Yes*. The connection with LQT will be terminated.




9. Click *OK*.




10. Select COM-port and click *Open*.




11. Click *Upgrade firmware*.




12. The upgrade is done.



13. Message that the upgrade was successful is shown. Click *OK*.




14. Click *Close* and restart LQT by interrupting the aux. supply.




5 Which COM-port is LQT using

In **Windows Device Manager** you find information about the COM-port that LQT is using. Below is a general description. It may differ between different Window versions, the principle is however the same.


1. Select *Start (Windowsflag)*, right click *My Computer* and select *Properties*.



2. Here you will find the information about the Windows version that is used and if it is 32-bit or 64-bit. Select *Device manager*.



- Expand *Ports (COM och LPT)*. Look for a unit with the name "STMicroelectronics Virtual COM Port". Within brackets you find the information about the COM-port of the unit.



6 Appendix

6.1 Technical data LQT400

Input	Voltage	
	Voltage range (Un)	100 – 400 V main voltage (nominal)
	Measuring range	0 – 500 V TRMS
	Overload voltage	1.5 x Un – continuously, 2 x Un – 10 s
	Consumption	U x 1 mA / phase
	Frequency	10... <u>40...70</u> ...120 Hz
	Current	
	Current (In)	1 – 5 A
	Measuring range	1 – 10 A TRMS
	Overload current	2 x In continuously, 10 x In 15 s, 40 x In 1 s
	Consumption	<0.05 VA / phase
	Aux. Supply	
		24 – 250 VDC
	80 – 250 VAC	
	Burden	max 8 VA
Output	Analog	
	Analog output	2
	Range	+/- 20 mA +/- 10 V (option)
	External resistance load	max 750 ohm (15V)
	Response time	<100 msec
General data	Accuracy	0.2
	Galvanic isolation	Supply, in- and output are galvanically isolated
	USB	1 port for configuration
	Temperature	-10...+55 °C (operation), -40...+70 °C (storage) Temperature coefficient less than 0.1% / 10 °C
	Test voltage	4 kV AC / min
	Inputs	overvoltage cat. III
	Outputs	overvoltage cat. II
	Pollution degree	2
	Dimension (B x H x D)	70 x 132 x 137 mm – DIN-rail
	Weight	ca 0.5 kg
	Standards	SS-EN 60688 Transducers SS-EN 601010 Safety EN 61000-6-2 / -6-4 / -6-5

6.2 Technical data LQT60

Inputs	Voltage	
	Input (Un)	100 – 400 V main voltage (nominal)
	Overload	1.5 x Un – continuously, 2 x Un – 10 s
	Measuring range	0 – 500 V TRMS
	Consumption (burden)	Un x 1 mA / phase
	Frequency	10... <u>40...70</u> ...120 Hz
	Current	
	Input (In)	1 – 5 A
	Overload	2 x In continuously, 10 x In 15 s, 40 x In 1 s
	Measuring range	0 – 10 A TRMS
	Consumption (burden)	<0.05 VA / phase
	Aux. supply	
		24 – 250 VDC
	80 – 250 VAC	
	Consumption max 8 W	
Outputs	Analog	
	Number	5 pcs
	Area	+/- 20 mA +/- 10 V (option)
	Load	max 750 ohm (15V)
	Response time	< 100 ms
	Digital	
	Number	2 transistor 110 V AC/DC, 100 mA
General data	Accuracy class	0.2
	USB	1 pc for configuration
	Temperature range	-10 to +55 C° (operation) -40 to +70 C° (storage) Temperature coefficient < 0.1% / 10 C°
	Test voltage	4 kV AC / min
	Inputs	Overvoltage cat. III
	Outputs	Overvoltage cat. II
	Pollution degree	2
	Dimensions (w x h x d)	150 x 70 x 73 mm – DIN-rail
	Weight	ca 0.5 kg
	Standards	SS-EN 60688 Transducers SS-EN 601010 Safety EN 61000-6-2 / -6-4 / -6-5